

Clear Window Perf Installation Instructions

Items you need:

1. Hard Plastic Squeegee
2. Isopropyl Alcohol
3. Clear Window Perf



How to install Clear Window Perf:

1. Prep surface by wiping the window with **Isopropyl Alcohol**.
2. Peel back **Clear Window Perf** from white backing.
3. Install **Clear Window Perf** on surface using a **Hard Plastic Squeegee**.
4. If the **Clear Window Perf** has a frosty look after it has been installed then there was not enough pressure applied to the material. Visually inspect the **Clear Window Perf** to make sure it does not look frosty.
5. If it looks frosty, apply pressure by using the squeegee over those areas.

DRY INSTALL ONLY
No Soapy Water
No Rapid Tac